


What is NXTServo-v3

NXTServo-v3 is an 8 channel Servo controller module. It allows you to control speed and position of up to 8 RC servo motors (or micro RC servos) using I2C commands sent from NXT.




Supported Servos

Any RC servo motor with "1500 μ S neutral" specifications.

The common brands available for this spec are: Hitec, Futaba. You could use 90° or 180° or continuous rotation servos.

Supported connectors: Futaba-J and Hitec-S compatible plugs.

Pictured as follows:



Power Supply

NXTServo module requires two different power sources. The power for logic section is 5 volts, and is taken from NXT, whereas, power for motors is taken from an external source. This power depends on capacity and ratings of the servos you will be using and the load they will be carrying.



NOTE

NXTServo is rated to handle maximum of 16 volts. However, most common RC servo motors are rated for much lower, and always ensure that you are not exceeding the rated voltage of your RC servo motor.



WARNING

While connecting to NXT, do not connect to Motor Port, doing so may damage the NXTServo circuit. (Always connect to Sensor Port).

As you attach more servos to NXTServo, more capacity batteries will be needed. Use following table as a general guideline in choosing external power source.

Function	Recommended battery
Upto 8 mini/micro servos, any load	6V - 4AA batteries
Upto 2 Standard RC Servos, moderate load	6V - 4AA batteries
Upto 6 mini/micro RC servos, moderate load	6V - 4AA batteries
Upto 4 standard RC servos, heavy load	7.2V - RC Lithium Polymer battery pack
8 RC servos, heavy load	7.5 V - RC NiMH battery pack



WARNING

While connecting the battery ensure to connect positive and negative terminals to correct connectors. NXTServo-v3 is designed such that reversed polarity will not operate your RC servos until polarity is corrected. However, reversed polarity for extended period may cause fire, damage NXTServo-v3 and/or your servo motors.


It is recommended to disconnect (or power-off) the external power from NXTServo while NXT is turned off. (While NXT is turned off, the connected servos will draw small amount of current from the external power source.)

Connections

Connect NXTServo to NXT using standard NXT cable supplied with Mindstorms kit or Flexi-cable from mindsensors.com.

Servo motors are connected directly on the NXTservo, with it's signal pin pointing towards the thick white line adjacent to the connector.

Connect the external battery to NXTServo while ensuring the correct polarity (as marked near the External Power Connector).



How to identify Signal Pin for common RC servos

Table below lists color coding for various servos available in market:

Wire colors (in following order)	Signal Pin
White/Red/Black	White
Yellow/Red/Black	Yellow
Orange/Red/Brown	Orange

The center pins is always power, and the remaining pin is always ground.

Programming Techniques

EV3:

To use capabilities of the sensor, please download NXT blocks available at following URL:

http://www.mindsensors.com/index.php?module=documents&JAS_DocumentManager_op=viewDocument&JAS_Document_id=235



Installation instructions for EV3 block are available at:

<http://www.mindsensors.com/pages/198>

Download EV3 sample program from following URL and modify it to suit your needs.

http://www.mindsensors.com/index.php?module=documents&JAS_DocumentManager_op=viewDocument&JAS_Document_id=247

NXT-G:

Download the NXT-G block that's available in the NXT-G Blocks Repository at Mindsensor's website. This block provides functionality for selecting a servo motor, setting its speed and position.



NOTE: While using with NXT-G, ensure to use latest firmware on your NXT.

RobotC:

Download the library file and sample programs available at following URL:

http://www.mindsensors.com/index.php?module=documents&JAS_DocumentManager_op=viewDocument&JAS_Document_id=68

You should include the library file (NXTServo-lib.c) in your program with #include directive, and use the API's provided by the library.

Alternately, you may modify the sample programs to suite your needs.

NXC:

Download the library file and sample programs available at following URL:

http://www.mindsensors.com/index.php?module=documents&JAS_DocumentManager_op=viewDocument&JAS_Document_id=84

You should include the library file (NXTServo-lib.nxc) in your program with #include directive, and use the API's provided by the library.

Alternately, you may modify the sample programs to suite your needs.



NOTE: While using with NXC ensure to use latest firmware on your NXT.

I2C register Summary

General Registers

Reg	Read	Write
0x41	Battery voltage (for EV3 compaaitible firmware, Battery Voltage is relocated to 0x62).	Control Register to write commands (see section on commands)

Servo Position Registers

Reg		
0x42	Servo 1 position: low byte time in μ S	Servo 1 position: low byte time in μ S
0x43	Servo 1 position: hi byte time in μ S	Servo 1 position: hi byte time in μ S
0x44	Servo 2 position: low byte time in μ S	Servo 2 position: low byte time in μ S
0x45	Servo 2 position: hi byte time in μ S	Servo 2 position: hi byte time in μ S
0x46	Servo 3 position: low byte time in μ S	Servo 3 position: low byte time in μ S
0x47	Servo 3 position: hi	Servo 3 position: hi byte

Reg		
	byte time in μ S	time in μ S
0x48	Servo 4 position: low byte time in μ S	Servo 4 position: low byte time in μ S
0x49	Servo 4 position: hi byte time in μ S	Servo 4 position: hi byte time in μ S
0x4A	Servo 5 position: low byte time in μ S	Servo 5 position: low byte time in μ S
0x4B	Servo 5 position: hi byte time in μ S	Servo 5 position: hi byte time in μ S
0x4C	Servo 6 position: low byte time in μ S	Servo 6 position: low byte time in μ S
0x4D	Servo 6 position: hi byte time in μ S	Servo 6 position: hi byte time in μ S
0x4E	Servo 7 position: low byte time in μ S	Servo 7 position: low byte time in μ S
0x4F	Servo 7 position: hi byte time in μ S	Servo 7 position: hi byte time in μ S
0x50	Servo 8 position: low byte time in μ S	Servo 8 position: low byte time in μ S
0x51	Servo 8 position: hi byte time in μ S	Servo 8 position: hi byte time in μ S

Speed Registers

Reg	Read	Write
0x52	Speed: Servo 1	Speed: Servo 1
0x53	Speed: Servo 2	Speed: Servo 2
0x54	Speed: Servo 3	Speed: Servo 3
0x55	Speed: Servo 4	Speed: Servo 4
0x56	Speed: Servo 5	Speed: Servo 5
0x57	Speed: Servo 6	Speed: Servo 6
0x58	Speed: Servo 7	Speed: Servo 7
0x59	Speed: Servo 8	Speed: Servo 8

Quick Registers

Reg	Read	Write
0x5A	NA	Position Servo 1
0x5B	NA	Position Servo 2
0x5C	NA	Position Servo 3
0x5D	NA	Position Servo 4
0x5E	NA	Position Servo 5
0x5F	NA	Position Servo 6
0x60	NA	Position Servo 7
0x61	NA	Position Servo 8

Register Descriptions

Servo Position Register

The position (low byte/high byte) is a 16-bit number, which directly sets the output pulse width in uS. Setting the position to 1500 (1500uS or 1.5mS) will typically set servos to their center position. The range of pulse widths that are normally supported are from 500uS (0.5mS) to 2500uS (2.5mS). Take care though, as it is easy to make the servo run into internal stops, if you give it pulse widths at the upper or lower extremes.

The registers can also be read back. The position will be the current position of the servo during a speed-controlled movement, so you can track its progress towards the requested position. Setting the servo position to 0 will deactivate the servo output (rendering servo in floating condition).

Servo Speed Register

The speed register controls the speed at which the servo moves to its new position. The servo pulses are automatically refreshed every 24mS. On power up the Speed registers are set to the EEPROM stored value stored using STORE command.

If the Speed register is zero (0x00) then the servo is simply set to the requested position at highest permissible speed.

If the Speed register is set to something other than zero, then that value is added to the current position every 24mS until the target position is reached. e.g. If you wish to move from 1000 to 2000 and the Speed register is set to 10, then it will take 2.4 seconds to reach the set position. The formula for the time it will take to make the move is: $((\text{Target position} - \text{Start position}) / \text{Speed Reg}) * 24\text{mS}$.

Control Register:

Control register allows you to change the I2C address of the device as well store and reset the start up conditions. By default, factory shipped NXTServo-v3 module has all registers set to 0x00. That is, all the servos are disabled on power up. However you can select the desired start up condition by storing it in the internal EEPROM.

Supported Commands:

CMD	Description
In	Store the initial speed and position properties of the servo motor 'n'. Current speed and position values of the nth servo is read from the servo speed register and servo position register and written to permanent memory.
S	Reset servo properties to factory default. (Initial Position of servos to 1500, and speed to 0)
H *	Halt Macro (This command re-initializes the macro environment)
R *	Resume macro Execution ((This command resumes macro where it was paused last, using the same environment)
Gx *	Go to EEPROM position x (This command re-initializes the macro environment)
EM *	Edit Macro
P *	Pause Macro (This command will pause the macro, and save the environment for subsequent resumption)

* Refer to NXTServo-Macro-Guide for further information about writing and running macros.

Quick Registers:

Quick register set allows quick change to the servo position (at a reduced resolution).

Although quick registers are not directly readable, the servo position can be read back using Servo Position Registers.

Quick registers are 1/10th the resolution of Servo Position Registers. The active value range of Quick registers is 50 to 250, where neutral position is at 150.

Software Revision Number:

Register 00 contains the software release number.

Current Release Number is 1.0 (0x0a).

Battery Voltage Register:

Voltage register contains value between 0 and 255 (with linear graduations), where value of 127 corresponds to 4700mV. Maximum voltage that can be reported is 9400 mV (corresponds to register value 255).

The register location is updated every 24mS, whether it is read or not.

I2C Address:

Factory shipped NXTServo module has address of 0xb0 on the I2C bus. This address can be changed to any thing above 0xa0. Control Register allows you to change the I2C address of the device.

Command Sequence to change the I2C address is:

```
0xa0 0xaa 0xa5 (new I2C address).
```

You can download the address change and scan functions from our website at www.mindsensors.com. These functions are written in RobotC.

Alternately, you can download NXT executable programs from following location: http://www.mindsensors.com/index.php?module=documents&JAS_DocumentManager_op=viewDocument&JAS_Document_id=91



NOTE

Any servo has physical limits to move from one position to the other. In general, an average RC servo takes about 120 milli-seconds for a 60 degree rotation. You may see jittery movement if your program is changing servo positions faster than physical limits of the servo.

Power On Position

When powered ON, the initial position of servo is set to neutral (i.e. 1500) and speed is set to 0.

Using Continuous Rotation Servos with NXTServo

Continuous rotation servo needs to be calibrated for neutral position (also known as stop position). Use following guide to understand and calibrate a CR servo:

http://www.mindsensors.com/index.php?module=documents&JAS_DocumentManager_op=viewDocument&JAS_Document_id=114

Following utility programs can be used in the calibration process:

http://www.mindsensors.com/index.php?module=documents&JAS_DocumentManager_op=viewDocument&JAS_Document_id=113

Current Consumption

NXTServo will draw about **3mA** current from NXT for its internal circuit.

The current consumption of servos driven by NXTServo is not part of this number.

Macros on NXTServo

For advanced operations, you can write macros for repetitive tasks and store them onto NXTServo. NXTServo can then run those commands independently from the NXT brick.

For example, if you are making a hexapod, where the 6 servos are moving in unison with each other, the movements of these servos can be coded in a macro and executed on NXTServo.

Please refer to NXTServo Macro Guide for further information.

http://www.mindsensors.com/index.php?module=documents&JAS_DocumentManager_op=viewDocument&JAS_Document_id=69

How to change default neutral position stored in NXTServo

When the NXTServo is powered on, it sets the servos to their neutral positions stored in NXTServo's memory. The factory default value of neutral position is 1500 μ S. It is possible to change these values so that when powered on, your servos will be set to your desired values.

Attach NXTServo to your NXT on port 1, attach power to NXTServo, and power on NXT.

Run program "init-neutral".

Attach a Servo to NXTServo on SV1 port. On NXT LCD screen select servo number '1', and press Orange button to continue.

On LCD screen scroll to desired position using arrow keys, (also look at your servo to ensure that it's not creeping) and press Orange button to store that value to NXTServo memory.

Follow the same procedure for as many servos as you need, connecting them to their respective ports on NXTServo.

You can download required programs here:

http://www.mindsensors.com/index.php?module=documents&JAS_DocumentManager_op=viewDocument&JAS_Document_id=113

